

Seabob serial number:



**SEABOB SERVICE FRANCE**

t: +33 767 25 22 44

e: [blaz@oceanpremium.com](mailto:blaz@oceanpremium.com)

Seabob pin code:    \_\_\_    \_\_\_    \_\_\_    \_\_\_

Seabob WiFi password:    \_ \_ \_ \_ \_

\*only for models with cameras

- How often should I charge my Seabob?

Charge your Seabob at least once per month.

- When do I use the transport mode?

When transporting by air or storing the Seabob for over one month.

- How do I set the depth limit?

Enter the Seabob menu with your pin code and set desired depth.

- Can I leave the charger connected all the time?

Yes. You still need to regularly check if the Seabob is taking charge.

- Can the Seabob battery be overcharged?

No.

- Accumulator overheating:

Disconnect the charger, place the Seabob in a cooler environment to stabilise.

- Accumulator error:

Put your Seabob in a cooler environment and put it on charge for 24 hours.

- Trigger is stuck or unresponsive:

Rinse it thoroughly while squeezing the trigger.

- Charging socket is wet:

Clean it with regular water and make sure it is dry before connecting the charger. Make sure protective cap is firmly tight before you put the Seabob back into water.

- Switch on:

blue - trigger

- Switch off:

silver - blue - trigger

- Menu access:

silver - blue - red

- Switch on storage mode:

Connect the charger and press the green button

- Switch off storage mode:

Connect the charger and press the red button

- Check usage time:

While the Seabob is on, press the blue button

**MAINTENANCE SCHEDULE:**[illegible]